



HIVE



♥ OF SAUNA



EN

Electric heater air tunnel

- Install an air tunnel between the heating elements of the heater. **See Figure.**
- Fill the heater with stones according to the instructions given in the HIVE electric heater manual.

The air tunnel supports the heating elements, creates efficient air movement in the heater, and speeds up the heating of the sauna room.

Find the latest updates on our website:
huumsauna.com

FR

Tunnel d'air pour poêle électrique

- Installez le tunnel d'air entre les éléments chauffants du poêle. Voir la **Figure**.
- Remplissez le réceptacle à pierres conformément aux instructions du manuel de poêle électrique HIVE.

Le tunnel d'air sert d'appui pour les éléments chauffants, assure un flux d'air plus efficace dans le poêle, ce qui permet de chauffer le sauna plus vite.

Vous trouverez sur notre site web toutes les informations dont vous avez besoin www.huumsauna.com

UK
RA



Made in Estonia, EU

info@huumsauna.com
huumsauna.com
[#huumsauna](https://twitter.com/huumsauna)

HUUM Sauna OÜ
Vahi tee 9
60534, Tartumaa
Estonia