



UK
CA

CE

EN Safety Railing

- Create full railing by connecting wood profiles with 4 corner plates.
- Screw the supports to the wood profiles without tightening the inner screw (for better placement afterward).
- Place the safety railing on the heater in a way that the heater's outer wall locks between the supports' side bends.
- Fix the untightened screws between the supports and wood profiles.
- Bend (using pliers) the lower ends of the supports tightly around the heater wall to fix the movement of the supports. Well done!
- Maintain the wooden parts of the guardrail with a breathable wood preservative to prolong its life. Use only products made for the sauna. Repeat the maintenance procedures at least once a year, but if you use the sauna often, you should also treat the wood more often.

Find the latest updates on our website
www.huumsauna.com

FR Garde-corps

- Fixez les éléments en bois au garde-corps à l'aide de 4 coins.
- Vissez les supports aux éléments en bois avec les vis, mais ne serrez pas la vis intérieure (pour ajuster le positionnement après).
- Installez le garde-corps sur le réceptacle à pierres de sorte que sa paroi extérieure se verrouille entre les coudes latéraux des supports.
- Serrez bien les vis non serrées entre les supports et les éléments en bois.
- Pliez (à l'aide de pinces) les extrémités inférieures des supports pour les serrer bien contre la paroi du réceptacle à pierres afin de bien fixer les supports. C'est fait!
- Entretenez les éléments en bois du garde-corps avec un agent de protection du bois offrant une protection respirante pour prolonger la durée de vie du bois. N'utilisez que les produits conçus pour le sauna. Enduisez le bois au moins une fois par an, mais si vous fréquentez souvent le sauna, le traitement plus fréquent ne sera pas de trop.

Vous trouverez sur notre site web toutes les informations dont vous avez besoin www.huumsauna.com



Made in Estonia, EU

info@huumsauna.com
huumsauna.com
[#huumsauna](https://www.instagram.com/huumsauna)

HUUM Sauna OÜ
Vahi tee 9, Tartu
60534, Estonia